

## How to renew the software

1. Copy the software into root directory of SD card.
2. Insert SD card into the device, it will show firmware update.



3. Please choose "yes, then it will show as below



4. Last it will show "Press OK button to reboot" .



5. Please delete the software in SD card, then the upgrade is finished.